

Property Owner Service Lateral Reference Procedure

Laterals with SDG&E

1. Obtain SDGE service order and following instructions
2. Obtain building permit
3. Hire electrician
4. Dig trench
5. Install SDGE conduit & connect to conduit stub provided by the city's contractor making sure there is at least 30" of cover with wire pull tape
6. Install pull can or new panel per SDGE service order
7. Call SDGE trench desk for inspection
8. Call Del Mar Building Department for inspection
9. Shade the electrical conduit in the trench with 6" of fill to allow for 6" of separation between SDGE & communications
10. Install AT&T & Spectrum conduits & connect to conduit stubs provided by the city's contractor with wire pull tape
11. Call Del Mar Building Department for inspection
12. Backfill trench

Laterals with Telecom Only

1. Obtain Building Permit
2. Dig Trench at least 24" deep to top of conduit.
3. Install AT&T & Spectrum conduits & connect to conduit stubs provided by the City's contractor with wire pull tape
4. Call Del Mar building department for inspection
5. Backfill trench

Service Cutover Coordination with SDG&E

1. Ensure your electrician is available within two weeks' notice to coordinate the cutover with SDG&E. The City recommends including a contract retainage with your contractor until the work is fully completed.